



# User Manual

## Contents

Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly. In the event of product failure within its intended use over the course of the first 3 years after date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product, please contact us via our helpline support services, details of which are to be found both in this manual and on the product itself.

# WORKZONE® RECHARGEABLE LED WORK LIGHT 10 W

- Scope of delivery.....3**
  - Components .....5
- General information.....6**
  - Reading and keeping the instructions for use ..... 6
  - Use for the intended purpose..... 6
  - Explanation of symbols ..... 6
- Safety .....7**
  - Explanation of notices .....7
  - General safety information ..... 8
- Setup.....12**
  - Checking the work light and package contents..... 12
  - Charging the work light..... 12
- Operation..... 13**
  - Using the battery as a power bank..... 13
- Cleaning..... 14**
- Storage ..... 14**
- Technical Data ..... 15**
- Declaration of compliance ..... 16**
- Disposal..... 16**
  - Disposal of packaging.....16
  - Disposing of the work light ..... 16



### PRODUCED IN CHINA FOR:

ALDI STORES LTD. PO BOX 26, ATHERSTONE  
WARWICKSHIRE, CV9 2SH

ALDI STORES (IRELAND) LTD.  
PO BOX 726, NAAS, CO. KILDARE.  
Visit us at [www.aldi.com](http://www.aldi.com)

**AFTER SALES SUPPORT** 803119

☎ **GB 01909 517672** **IE 012 475 437**

💻 **aldi@0800repair.com**



---

MODEL: 937 01/2021

**3**  
YEAR  
WARRANTY



# Scope of delivery



## Components

- 1 Carry handle
- 2 USB charging cable
- 3 Battery charge level indicator
- 4 Button for battery charge level indicator
- 5 Micro-USB socket
- 6 USB socket
- 7 Protective cover
- 8 On/Off switch

The specifications supplied include a built-in Li-ion rechargeable battery (4400 mAh).

## General information

### Reading and keeping the instructions for use



These instructions for use belong together with the rechargeable LED work light (referred to below as “the work light”). They contain important information about handling and setting up the product.

Carefully read through the instructions for use and especially the safety instructions before using the work light. Failure to observe these instructions for use could result in serious personal injury or damage to the work light.

These instructions for use are based on the standards and regulations applicable in the European Union. For use abroad, please also observe country-specific standards and local laws.

Keep these instructions safe for future reference. If you pass on the work light to someone else, please make sure that you also give them the instructions for use.

### Use for the intended purpose

This work light is designed exclusively for illuminating indoor and outdoor working areas. It is intended solely for personal use and is not suitable for trade use.

You should only use the work light as described in these instructions for use.

The working light is designed for handheld use only. Any other use is considered improper and may lead to material or personal damage. The work light is not a toy.

The manufacturer or dealer does not accept any liability for damages that occur due to use other than according to the intended purpose or to improper use.

### Explanation of symbols

The following symbols are used in these instructions, on the product itself or on the packaging.



This symbol indicates useful additional information about operation.




Declaration of conformity (see chapter "Declaration of conformity"): Products marked with this symbol comply with all applicable European Economic Area regulations.



This symbol indicates electrical equipment that complies with protection class III. That means that the work light runs on low-voltage electricity and is operated by a safety extra-low voltage (SELV).



This symbol indicates that a device operates under direct current.



USB connection

## Safety

### Explanation of notices

The following symbols and signal words are used in these instructions for use.



This signal symbol / word indicates a moderate degree of risk. If this risk is not avoided, it may lead to death or severe injuries.



This signal symbol / word indicates a low degree of risk. If this risk is not avoided, it may lead to minor or moderate injuries.



This signal word indicates possible material damage.

## General safety information



### Electrical shock hazard!

Incorrect electrical installation or a power supply voltage that is too high can potentially cause electric shocks.

- Only plug in the work light if the mains voltage of the power outlet socket matches the voltage indicated on the identification plate.
- You should only connect the work light to an easily accessible power outlet socket so that you can quickly disconnect it from the power supply in the event of a fault.
- Never operate the work light if it shows visible signs of damage or if the power cord or mains plug is faulty.
- Do not open up the casing and only have the product repaired by qualified professionals. To that end you should contact a specialist repairer. Liability or warranty claims are excluded, if repairs are carried out independently, and if the device is not connected or handled properly.
- The product may only be repaired using parts that match the original equipment specifications. This work light contains electrical and mechanical components that are indispensable for protection against sources of danger.
- Do not immerse the work light in water or any other liquids.
- Do not position the work light above bathtubs, washbasins or other objects filled with water.
- Never reach after an electrical device that is connected to the power supply if it falls into water. In such cases you should immediately unplug the mains plug from the power outlet socket.
- Never pull on the USB charging cable to unplug the USB power adaptor from the power outlet socket; always take hold of the USB power adaptor itself.

- Keep the work light and the USB charging cable away from naked flames and hot surfaces.
- Do not kink the USB charging cable and do not run it over sharp edges.
- Do not use the work light in wet areas or in the rain.
- When the battery is fully charged, if you wish to clean the work light or if a fault occurs, always switch the work light off and unplug the USB power adapter from the power outlet socket.
- Keep the work light and the USB charging cable away from children.
- The rechargeable battery in the work light cannot be replaced. Never attempt to replace the rechargeable battery.
- Only recharge the battery of the work light indoors.



### **Risks for children and individuals with limited physical, sensory, or mental abilities (such as partially disabled people, elderly people with limited physical and mental capacities), or a lack of experience and knowledge (such as older children).**

- This work light can be used by children aged 8 years and over, as well as by persons with limited physical, sensory or mental abilities or lacking in experience and knowledge, if they are supervised or have been instructed as to the safe use of the product and understand the resulting hazards. Children must not be allowed to play with the work light. Cleaning and maintenance may not be carried out by children without proper supervision.
- Keep children under 8 away from the work light and the power cord.
- Do not let children play with the packaging film. Children may get caught in the packaging film while playing and suffocate.

**WARNING!****Risk of explosion and fire!**

Incorrect handling of the work light or the rechargeable battery can potentially cause an explosion or fire.

- Keep the work light away from water, other liquids, naked flames and hot surfaces.
- Do not cover the work light or the USB power adaptor with objects or clothing.
- Keep the product at least 5 cm away from easily combustible materials.
- Do not expose the work light to excessive heat such as direct sunlight, fire or the like.
- Only charge the work light with the accessories supplied.

**WARNING!****Risk of chemical burns!**

Leaking battery fluids may cause chemical burns upon contact with skin or other parts of the body.

- If fluid leaks out of the battery, avoid contact with skin, eyes and mucous membranes. In the event of skin contact, rinse the affected area immediately with plenty of clean water, and seek medical advice without delay.
- If the battery is leaking, first make sure you are wearing protective gloves and then remove leaked battery fluid with a dry, absorbent cloth.

**ATTENTION!****Danger of injury!**

The LED light is very bright and may damage your eyes if you look directly at it.

- Never look directly into the LED light of the work light when it is switched on.
- When using the work light, be careful not to shine it into the eyes of other people or animals.

**PLEASE NOTE!****Risk of damage!**

Incorrect handling of the work light may potentially damage it.

- The light source of this work light cannot be replaced. If the light source has reached the end of its service life, replace the entire work light.
- Stand the work light on an easily accessible, level, dry, heat-resistant and sufficiently stable surface. Do not position the work light near the edge of the surface.
- Never stand the work light on or near hot surfaces (cooker hobs, etc.).
- Do not allow the USB charging cable to come in contact with hot items.
- Do not expose the work light to the weather (rain, etc.).
- Do not use the work light for more than 3 hours at a time. To prevent harmful deep discharging, please recharge the battery after this period of use.
- If you are not going to use the work light for an extended period of time, fully charge the battery before storing the work light away.
- The work light is dimmable and must not be operated with an external dimmer.

## Setup

### Checking the work light and package contents

#### PLEASE NOTE!

#### Risk of damage!

If you open the packaging carelessly with a sharp knife or other sharp objects, the work light could easily be damaged.

- Be very careful when opening the packaging.
  1. Remove the work light from the packaging.
  2. Check that all package contents are present (see **Fig. A**).
  3. Check if there is any damage to the work light or the individual components. If that is the case, do not use the work light. Please contact the manufacturer via the service address indicated on the warranty card.

### Charging the work light

Before using the work light for the first time, you must fully charge its battery. Charging the battery takes approx. 6 hours.

#### PLEASE NOTE!

#### Risk of damage!

Incorrect handling of the work light may potentially damage it.

- Always switch off the work light while it is being charged.
  1. Make sure that the work light is switched off.
  2. Fully unwind the USB charging cable **2**.
  3. Plug the micro-USB connector into the micro-USB socket **5** on the work light. To do so, lift up the protective cover **7** (see **Figs. A and B**).
  4. Plug the cable into a USB port on a computer, laptop, etc. The battery charge level indicator **3** flashes green while the battery is being charged (see **Fig. B**).
  5. As soon as the battery is fully charged, all three battery charge level indicator lights will show blue. Disconnect the work light from the power supply.

## Operation



The work light cannot be used while it is being charged.

The work light offers two brightness levels (100% and 50%).

1. To check the charge level of the battery, press the battery charge level indicator button **4** (see **Fig. B**). If the battery is fully charged, all three battery charge level indicator lights **3** will show blue. The lower the charging level, the lower the number of active indicator lights. If the battery is fully charged, the work light can be used for approx. 2 hours (100%) / 4 hours (50%).
2. Use the carry handle **1** to carry the work light to where you wish to use it.
3. To switch on the work light, press the On/Off switch **8** (see **Fig. B**). The LED will then switch on at 100% brightness.
4. To reduce the brightness, very lightly press the On/Off switch. The LED will then switch to 50% brightness.
5. To set up the work light, tilt the carry handle so that the light shines on the work area at the desired angle.
6. To switch off the work light, press the On/Off switch.

### Using the battery as a power bank

- Connect the device you wish to charge to the work light using a USB charging cable by plugging the USB connector into the USB socket **6** (see **Fig. B**).

## Cleaning

### PLEASE NOTE!

#### Risk of damage!

Incorrect handling of the work light may potentially damage it.

- Do not use aggressive cleaning agents, brushes with metal or nylon bristles and also not sharp or metallic cleaning objects such as knives, hard spatulas or similar objects. These can damage the surface.
- Do not immerse the work light, the USB charging cable or the USB power adaptor in water in order to clean them and never under any circumstances put them in a dishwasher.
- Do not clean the work light or the USB charging cable under running water or spray them with a garden hose or a pressure washer.
- Remove dust and dirt from the work light with a soft, slightly dampened cloth.
- For stubborn dirt, use a mild detergent if necessary.

#### Storage

- Before storing the work light away, fully charge the battery (see section headed “Charging the work light”).
- Always store the work light in a dry place where it is protected from direct sunlight and inaccessible to children.

## Technical data

### Work light

Model:	937
Article no.:	803119
Material:	Casing: Plastic Carry handle: Plastic
Size:	170 x 125 x 45 mm
Weight:	485 g
Input voltage:	5 V $\text{---}$
Protection class:	III
Light source:	COB-LED chip, permanently installed
LED output:	10 W
Light current:	800 lm (100 % brightness) 400 lm (50 % brightness)
Service life:	50 000 h
Max. projection area:	16 cm <sup>2</sup>
Battery type:	Li-Ion, 4 400 mAh
Risk group (according to EN 62471:2008):	1
Protection class:	IP 54 – Protected against ingress of dust and splashwater
Minimum distance to illuminated objects:	10 cm
Power bank output voltage:	5 V, 1 A

## Declaration of compliance



The EU Declaration of Conformity can be requested from the address provided in the attached warranty.

## Disposal

### Disposal of packaging



Dispose of the packaging according to material. Add cardboard and carton to the waste paper, films to the recyclable materials.

### Disposing of the work light

(Applicable in the European Union and other European states that have systems for collecting recyclable materials)



#### **Old electrical devices must not be disposed of as household waste!**

If the product is no longer usable, consumers are **legally obliged to dispose of used appliances separately from household waste**, e.g. at a recycling centre in their local community or district. It is thus ensured that old devices are properly recycled, and that negative impact on the environment is avoided. This is why electrical devices are marked with this symbol.



#### **Batteries and rechargeable batteries must not be disposed of with household waste!**

As a consumer, you are legally obliged to dispose of all batteries, whether they contain harmful substances\* or not, at a collection point in your municipality/city district or in trade, so that they can be disposed of in an environmentally friendly manner.

Take the complete work light (including the battery) to your local recycling centre, making sure that the battery is fully discharged!

\*labelled with: Cd = cadmium, Hg = mercury, Pb = lead